

RF INTERFACE 1 AND 2FT

For remote mount Installation Instructions

RFS

1 / 2



NMT-20-1127-02

1

RF Interface — x 1

M5x12 — x 2

2

O Ring
Kept in place

Turn while
pushing
down

3

Vertical

Horizontal

RF INTERFACE 1 AND 2FT

For remote mount Installation Instructions

RFS

2 / 2



NMT-20-1127-02

4

M5 x 12 — x 2

5

Optional fine polarization adjustment

6

Final tightening

3 N.m