

# RF Interface 6FT CLS 4

For remote mount Installation Instructions



# RF Interface 6FT CLS 4

For remote mount Installation Instructions



NMT-20-1300-00(e)

NMT-20-1300-00(e)

**1**

RF Interface

Adapter

GREASE

GREASE

Basic Feed

**FOR 6, 10/11 GHz**

RF Interface — x1

M5x12 — x2

M5 x 20 — x4

L5.3 — x4

W5 — x4

Basic Feed — x1

Ring — x1

M4 x 10 — x4

**3**

Basic Feed

**FOR 6, 10/11 GHz**

Basic Feed — x1

Ring — x1

M4 x 10 — x4

GREASE

2.5 N.m

**2**

**FOR 6, 10/11 GHz**

Adapter — x1

**FOR 6, 10/11 GHz**

M5 x 20 — x4

L5.3 — x4

W5 — x4

GREASE

5 N.m

**4**

O Ring Kept in place

Turn while pushing down

# RF Interface 6FT CLS 4

For remote mount Installation Instructions



NMT-20-1300-00(e)

